

1 **Supplementary Methods**

2

3 **Raw DNA methylation data processing**

4 Raw EPIC array intensity values were processed using the Minfi package of the R
5 environment for statistical computing. After background correction we excluded
6 methylation markers with detection p-value $>10^{-16}$ in $>20\%$ of samples and
7 samples/patients with a call rate $<90\%$ prior to functional normalization.(1)
8 Principal component analysis (PCA) based on gonosomal methylation markers
9 was used to verify correct gender annotation (n=1 sample excluded).
10 Methylation markers on gonosomes, cross-reactive/multi-mapping, non-CpG
11 probes or with an inconsistent base extension were excluded.(2,3) Sensitivity of
12 findings was assessed using the GenomeStudio software (v2011.1) Methylation
13 Module (v1.9.0) for initial quality control: Methylation markers with detection p-
14 value >0.01 in $>20\%$ of the samples and samples with a call rate $<80\%$ were
15 removed prior to quantile normalization per entity and across entities.

16

17 **Differential methylation analyses**

18 The 80% most variable probes by median absolute deviation (MAD) were used
19 for nonparametric Jonckheere–Terpstra tests to identify markers with gradient
20 methylation levels (increasing or decreasing) along the sequence GSD→low-
21 grade dysplasia→high-grade dysplasia→GBC. P-values were adjusted for multiple
22 testing using Bonferroni–Holm correction. Adjusted p-values <0.05 were
23 considered to indicate a gradual methylation change. Methylation differences
24 between disease groups were quantified using linear models adjusting for
25 patient’s age and gender. Methylation markers were annotated with functional
26 elements and genes using the Illumina Infinium MethylationEPIC BeadChip
27 annotation manifest.(4) PANTHER (v14, www.pantherdb.org) gene ontology
28 (GO) enrichment analyses was done based on genes with differentially
29 methylated markers. Differentially methylated regions (DMRs) are groups of
30 neighboring methylation markers that share a significant methylation difference
31 between two groups of samples (more than one DMR may occur per gene). DMRs
32 in gene/isoform related promoters for GSD plus low-grade dysplasia samples,

33 compared with high-grade dysplasia plus GBC samples, were identified with the
34 ChAMP R-package. (5)

35

36 **CNV analysis**

37 Copy number variations (CNVs) were assessed based on methylation array signal
38 intensities using the conumee R package. Copy number segmentation was
39 performed using standard parameters with GSD samples as the reference
40 category and LogR thresholds of ± 0.15 to identify altered segments.(6,7) The
41 segmented data from GBC patients were additionally analyzed using GISTIC2.0
42 with the default parameters to identify segments recurrently altered.(8)

43

44 **mRNA expression analysis**

45 Total RNA was isolated from OZ and G-415 using standard protocols (Qiagen).
46 cDNA was generated from 1.0 μg DNase I-treated RNA using SuperScript III
47 Reverse Transcriptase (Invitrogen) and random hexamers (QIAGEN) and
48 expression analyzed with a LightCycler 480 real-time PCR system (Roche) using
49 human Universal ProbeLibrary hydrolysis probes (Roche), and LightCycler DNA
50 Probes Master polymerase mix (Roche). Data were normalized to the average of
51 the three housekeeping genes beta actin (*ACTB*), glyceraldehyde-3-phosphate
52 dehydrogenase (*GAPDH*) and hypoxanthine phosphoribosyltransferase 1
53 (*HPRT1*) to calculate relative gene expression. Primer design: Universal
54 ProbeLibrary Assay Design Center (Roche)(**Suppl. Table S1**).

55

56 **Epigenome-wide DNA methylation and RNA-sequencing data for G-145**

57 For G-415 epigenome-wide DNA methylation data, generated using the same
58 methodology as for tissue samples, and RNA-sequencing data were available.
59 RNA sequencing libraries were prepared from 1.5 μg of total RNA using the
60 NEBNext Ultra II Directional RNA Preparation Kit with the NEBNext Poly A
61 Selection Module, and the NEBNext Multiplex Oligos for Illumina. Libraries were
62 quantified on the Qubit (Thermo Fisher), quality-checked (DNA 1000 Chip;
63 Agilent Bioanalyzer), pooled and then sequenced (Illumina HiSeq 2500, 125bp
64 paired-end mode). Raw reads were quality controlled and filtered with FastQC
65 (v0.11.2) (bioinformatics.bbsrc.ac.uk/projects/fastqc) and PRINSEQ (v0.20.3)

66 before alignment with STAR (2.5.2b) against GRCh38.90 reference genome and
67 quantification with the Subread R package (v1.6.4).

68

69 **qPCR expression analysis**

70 cDNA was generated from 1.0 µg DNase I-treated total RNA using SuperScript III
71 Reverse Transcriptase (Invitrogen) and random hexamers (QIAGEN). Expression
72 was analyzed with a LightCycler 480 real-time PCR system (Roche) using human
73 Universal ProbeLibrary hydrolysis probes (Roche), and LightCycler DNA Probes
74 Master polymerase mix (Roche). Data were normalized to the average of the
75 housekeeping genes beta actin (*ACTB*), glyceraldehyde-3-phosphate
76 dehydrogenase (*GAPDH*) and hypoxanthine phosphoribosyltransferase 1
77 (*HPRT1*). **Suppl. Table S1** shows the primers used (Universal ProbeLibrary
78 Assay Design Center, Roche).

79

80 **Immunohistochemistry assays for *CDO1***

81 Staining was performed on an automated immunostainer (Ventana BenchMark
82 Ultra, Ventana Medical Systems, Tucson, USA) with the OptiView DAB IHC
83 Detection Kit (Ventana Medical Systems). FFPE tissue sections were
84 deparaffinized and rehydrated prior to heat-induced epitope retrieval. After
85 blocking endogenous peroxidase, slides were incubated with the antibody LS-
86 B12120 (*CDO1*, Biozol, USA), followed by incubation with OptiView Universal
87 Linker and OptiView HRP Multimer. DAB-Chromogen images were classified by
88 five trained pathologists (IG, FG, MTR, EM and GdT) into the categories negative,
89 weak or strong, and discordant classifications were resolved by majority vote.
90 *CDO1* was stained in two separate sets of samples: (1) eleven slides (GSD n=5
91 and GBC n=6) that were left after conducting the EPIC, MassARRAY, RNAseq and
92 qRT-PCR assays described in the manuscript and (2) twenty slides from an
93 independent group of ten Chilean GBC patients with paired tumor and adjacent
94 non-tumor samples.

95

96 **Dual-color chromogenic ERBB2 in situ hybridization**

97 Dual-color chromogenic in situ hybridization (dc-CISH) was performed as
98 reported previously using the ZytoDot 2C SPEC ERBB2/CEN 17 Probe Kit

99 (Zytovision, Bremerhaven, Germany), which contains a digoxigenin-labeled
100 probe specific for the ERBB2 locus at 17q12 and a dinitrophenyl-labeled probe
101 specific for the alpha satellite centromeric region of chromosome 17.(9) In brief,
102 tissue sections were deparaffinized and incubated with H₂O₂ to block
103 endogenous peroxidase followed by incubation in a preheated EDTA
104 pretreatment solution at 98 °C in a water bath. Thereafter, proteins were
105 denatured in a humidity chamber using pepsin solution. After dehydration
106 through an ethanol series, 10 µl of the ZytoDot 2C SPEC ERBB2/CEN 17 Probe
107 was applied to each slide, which were then covered with slide glass coverslips
108 and sealed with rubber cement (Fixogum; Marabu, Tamm, Germany). The slides
109 were denatured at 78 °C for 5 min and hybridized at 37 °C in a humidified
110 hybridization chamber (ThermoBrite™, Abbott Molecular, Chicago, IL, USA)
111 overnight. Immunodetection was performed according to the manufacturer's
112 instructions followed by counterstaining with nuclear blue solution.

113

114 **References**

- 115 1. Fortin J-P, Labbe A, Lemire M, Zanke BW, Hudson TJ, Fertig EJ, et al.
116 Functional normalization of 450k methylation array data improves
117 replication in large cancer studies. *Genome Biol.* 2014;15:503.
- 118 2. Zhou W, Laird PW, Shen H. Comprehensive characterization, annotation and
119 innovative use of Infinium DNA methylation BeadChip probes. *Nucleic Acids*
120 *Res.* 2016;45:e22.
- 121 3. Pidsley R, Zotenko E, Peters TJ, Lawrence MG, Risbridger GP, Molloy P, et al.
122 Critical evaluation of the Illumina MethylationEPIC BeadChip microarray for
123 whole-genome DNA methylation profiling. *Genome Biol.* 2016;17:1–17.
- 124 4. Moran S, Arribas C, Esteller M. Validation of a DNA methylation microarray
125 for 850,000 CpG sites of the human genome enriched in enhancer
126 sequences. *Epigenomics.* 2016;8:389–399.
- 127 5. Morris TJ, Butcher LM, Feber A, Teschendorff AE, Chakravarthy AR, Wojdacz
128 TK, et al. ChAMP: 450k Chip Analysis Methylation Pipeline. *Bioinformatics.*
129 2014;30:428–430.
- 130 6. Capper D, Stichel D, Sahm F, Jones DTW, Schrimpf D, Sill M, et al. Practical
131 implementation of DNA methylation and copy-number-based CNS tumor

- 132 diagnostics: the Heidelberg experience. *Acta Neuropathologica*.
133 2018;136:181–210.
- 134 7. Stone TJ, Keeley A, Virasami A, Harkness W, Tisdall M, Delgado EI, et al.
135 Comprehensive molecular characterisation of epilepsy-associated
136 glioneuronal tumours. *Acta Neuropathologica*. 2017;135:115–129.
- 137 8. Mermel CH, Schumacher SE, Hill B, Meyerson ML, Beroukhim R, Getz G.
138 GISTIC2.0 facilitates sensitive and confident localization of the targets of
139 focal somatic copy-number alteration in human cancers. *Genome Biol*.
140 2011;12:R41.
- 141 9. Albrecht T, Rausch M, Roessler S, Geissler V, Albrecht M, Halske C, et al.
142 HER2 gene (ERBB2) amplification is a low-frequency driver with potential
143 predictive value in gallbladder carcinoma. 2019;;1–10.

1 **Suppl. Figure legends**

2

3 **Suppl. Figure S1**

4 **A–D)** Distribution of normalized methylation values in the four investigated
5 groups of patients for the markers with the smallest p-values from Jonckheere–
6 Terpstra tests.

7

8 **Suppl. Figure S2**

9 **A)** Proportion of markers in functional genetic elements such as gene bodies and
10 promoters (TSS200, TSS1500) among those with gradient (red) and nongradient
11 (gray) methylation values as determined using the Jonckheere–Terpstra (JT) test.
12 (Differences in proportions were tested using the proportion z-test per element
13 category.) **B)** Age- and sex-adjusted methylation differences between GBC and
14 gallstone samples for markers in Phantom5 enhancer regions. **C, D)** Enrichment
15 analysis of genes with gradient methylation values along the sequence of GSD →
16 Dysplasia → GBC based on JT test using the PantherDB gene ontology (GO)
17 database and the PantherDB Molecular Pathways.

18

19 **Suppl. Figure S3**

20 **A,B)** Pooled methylation values for markers in the promoter-associated CpG
21 islands of the indicated genes for GBC patients grouped by T stage **(A)** and M stage
22 **(B)**. **C)** Distribution of methylation values across markers of the CpG island in the
23 *TWIST1* promoter. **D)** Pooled methylation values of *TWIST1* CpG markers in C) for
24 GBC patients grouped by tumor grade (left) and T stage (right). **E)** Methylation
25 values across markers of the CpG island in the *HBE1* promoter (left) and pooled
26 beta values for these markers in GBC patients by T stage (right). **F)** Methylation
27 values across markers of the CpG island in the *RPL22* promoter. (All p-values from
28 ANOVA tests adjusting for baseline CpG differences; green = GSD, light green = LG-
29 dysplasia, light red = HG-dysplasia, red = GBC)

30

31

32

33

34 **Suppl. Figure S4**

35 **A)** Comparison of age- and sex-adjusted methylation difference between GSD and
36 GBC samples after Minfi- or GS-based selection for markers significant in Minfi-
37 based JT tests. **B)** Comparison of JT test p-values after Minfi- or GS-based selection
38 for all shared markers. **C)** Results of differentially methylated region analysis in
39 candidate genes based on GS-based marker selection/pre-processing. In CDO1
40 and ZSCAN18 two DMRs were detected.

41

42 **Suppl. Figure S5**

43 Results from GISTIC2.0 analyses displaying regions with copy number gains **(A)**
44 and losses **(B)** in GBC patients. False discovery rate (FDR)-corrected p-values are
45 indicated on the bottom axis; the names of potentially relevant candidate genes
46 are given (green line: FDR threshold at 0.1).

47

48 **Suppl. Figure S6**

49 **A)** Number of genes per sample with RNAseq mRNA expression data that fulfilled
50 the quality control filters across disease groups. The p-value is based on a Kruskal-
51 Wallis test. **B)** Correlation between β values of CpGs shown in **Figure 4B** and
52 RNAseq mRNA expression in samples with high quality data (n=51). Pearson
53 correlation coefficients and the corresponding p-values are shown **C)** RNAseq
54 mRNA expression for three genes previously reported as hypermethylated and
55 underexpressed in Indian GBC patients (10). P-values are based on Jonckheere-
56 Terpstra tests across disease groups.


57

58 **Suppl. Figure S7**


59 **A)** Representative images showing CDO1 IHC staining in GSD (top) and GBC
60 (bottom) samples. **B)** Association between CDO1 IHC staining categories and
61 CDO1 methylation for CpG cg16707405 for samples with available EPIC
62 methylation data (n=10), which were also investigated in the validation analyses,
63 please see **Figure 4A**, **Figure 4C** and **Suppl. Figure S6B**. P-values based on
64 Jonckheere-Terpstra tests across IHC categories. **C)** Representative images
65 showing CDO1 IHC staining in an independent group of Chilean GBC patients with
66 paired adjacent non-tumor (top) and tumor (bottom) samples.

Suppl. Figure S1


A




B







C



D




Suppl. Figure S2




Suppl. Figure S3


A




B




C




D



E




F




Suppl. Figure S4


A



B




C




Suppl. Figure S5

A




B




Suppl. Figure S6


A



B




C




Suppl. Figure S7


A



B



C



Suppl. Table S1. DNA oligonucleotides used for DNA methylation analysis and qRT-PCR. UPL: LightCycler 480 Universal ProbeLibrary, Roche

Name	Forward primer sequence	Reverse primer sequence	Chromosomal location (hg19)
EpiTYPER primers for methylation analysis¹			
covered cg probes			
RUNX3 cg26421310	GAAGTAGTAAGAGTTGGGGAAGTT	CAATACCACAACCCAAAACCC	chr1:25,256,961-25,257,156 chr1:25,257,058
CD01 cg16707405	TTTAGATTTGTGGGGTTTATTTTTT	CCACCTTTCTTAAATAACTCT CC	chr5:115,152,346-115,152,459 chr5:115,152,414
TP73 promotor cg04493946 cg27340829	GTTTTGGTGGGTTTAATTATGGAGT	AAACAAACCTCAACTTACCC	chr1:3,607,072-3,607,179 chr1:3,607,098 chr1:3,607,143
TP73 distant promotor cg24678611 cg10038618 cg07382920	GGGTTTAGTTTTGGTAATAGAAAAGC	CCTAACCTTAAATTCTAAAAA CT	chr1:3,567,593-3,567,766 chr1:3,567,732 chr1:3,567,719 chr1:3,567,647
HMGA1 cg08335767 cg10610528	GGTTTTGATGTTTAGAAATAGGTGG	TACTAAAAACCTTTAATCCCC TCA	chr6:34,206,459-3,420,6578 chr6:34,206,495 chr6:34,206540
LINE-1	TTTATATTTTGGTATGATTTTGTAG	TTTATCACCACCAAACCTACCC T	chrX:146,737,074-146,737,176
RT-qPCR primers (UPL hydrolysis probe)			
RUNX3 (#71)	TCAGCACCACAAGCCACTT	AATGGGTTTCAGTTCGAGGT	
CD01 (#74)	TCTCTGTTGGGGTGAAGGAC	AAGCAGTGGGAGTTGGTATGA	
TP73 (#19)	GGAGGGACTTCAACGAAGG	TCATCCACATACTGCGAGAGA	
HMGA1 (#75)	GGAAAAGGACGGCACTGA	ACTTCGCTGGGCTCCTTC	
ACTB (#11)	ATTGGCAATGAGCGGTTC	GGATGCCACAGGACTCCAT	
GAPDH (#60)	GCCAATACGACCAAATCC	AGCCACATCGCTCAGACAC	
HPRT1 (#73)	TGACCTTGATTTATTTTGCATA CC	CGAGCAAGACGTTTCAGTCCT	

¹Primers were 5'-tagged with tags for EpiTYPER analysis (forward primer: AGGAAGAGAG, reverse primer: CAGTAATACGACTCACTATAGGGAGAAGGCT).

Supplementary Table S2: Clinical characteristics of the investigated Chilean cohort (total n=81 patients)

Gallstone disease (n=32 patients)	
Median age	48.5 years
Gender (f/m)	30/2
Low-grade dysplasia (n=13 patients)	
Mean age	53 years
Gender (f/m)	11/2
With gallstones	13
High-grade dysplasia (n=9 patients)	
Mean age	67.5 years (missing information for 1 patient)
Gender (f/m)	7/2
With gallstones	9
Gallbladder cancer (n=27 patients)	
Mean age	62 years (missing information for 2 patients)
Gender (f/m)	21/5 (missing information for 1 patient)
With gallstones	25 (missing information for 2 patients)
T stage	
In situ	2
T1	6
T2	10
T3	4
T4	2
Not available	3
N stage	
NX	6
N0	15
N1	2
N2	1
Not available	3
M stage	
MX	9
M0	11
M1	4
Not available	3
Grading	
G1	7
G2	11
G3	2
Not available	7

Supplementary Table S3: Top significant CpG markers with differential methylation in Jonckheere-Terpstra (JT) test. p-values were Bonferroni-Holm adjusted, b-differences were calculated from linear models adjusting for patient age and gender.

No.	Methylation marker	Gene	adj. JT p-value	Mean β -value in gallstone samples	Mean β -difference LG-dyspl. vs gallstone	Mean β -difference HG-dyspl. vs gallstone	Mean β -difference GBC vs gallstone
1	cg08493776	PCDHB6	0	0.04 (0;0.14)	0.02 (-0.05;0.1)	0.19 (0.09;0.28)	0.26 (0.19;0.33)
2	cg21392341	TBX15	1.1e-10	0.03 (0;0.14)	0.01 (-0.07;0.1)	0.15 (0.04;0.26)	0.21 (0.13;0.28)
3	cg02164046	SST	3.7e-10	0 (0;0.09)	0.06 (-0.04;0.16)	0.26 (0.13;0.38)	0.36 (0.27;0.44)
4	cg24886257		8.7e-10	0.12 (0;0.26)	0.07 (-0.04;0.18)	0.23 (0.09;0.36)	0.35 (0.26;0.45)
5	cg11823511	BARHL2	1.6e-09	0 (0;0.11)	0.02 (-0.07;0.12)	0.24 (0.12;0.36)	0.29 (0.21;0.38)
6	cg00656990	WWOX	3.2e-09	0.89 (0.8;0.98)	-0.02 (-0.08;0.05)	-0.17 (-0.26;-0.08)	-0.21 (-0.27;-0.15)
7	cg24503966	NOL4	3.8e-09	0.04 (0;0.15)	0.03 (-0.05;0.1)	0.13 (0.03;0.23)	0.23 (0.17;0.3)
8	cg02950416	BCAN	4.3e-09	0 (0;0.1)	0.03 (-0.05;0.1)	0.14 (0.04;0.24)	0.28 (0.22;0.35)
9	cg26958783	SALL3	4.3e-09	0.1 (0.02;0.17)	0.03 (-0.03;0.08)	0.16 (0.09;0.24)	0.16 (0.11;0.21)
10	cg18359578	KCNMA1	5.5e-09	0.4 (0.35;0.45)	-0.04 (-0.08;0)	-0.11 (-0.17;-0.06)	-0.14 (-0.18;-0.1)
11	cg26296488	DRD5	6.2e-09	0.02 (0;0.18)	-0.01 (-0.12;0.11)	0.2 (0.05;0.34)	0.36 (0.26;0.46)
12	cg12665460	ZNF578	6.2e-09	0.13 (0.05;0.22)	0 (-0.06;0.07)	0.11 (0.03;0.2)	0.21 (0.16;0.27)
13	cg19274890	DPP6	6.2e-09	0 (0;0.09)	-0.01 (-0.11;0.08)	0.26 (0.13;0.38)	0.37 (0.29;0.46)
14	cg05928342	ZNF177	7.2e-09	0.04 (0;0.14)	0.01 (-0.07;0.08)	0.07 (-0.03;0.17)	0.23 (0.16;0.3)
15	cg02519751	ZIC1	7.7e-09	0.08 (0;0.22)	0.05 (-0.05;0.15)	0.27 (0.14;0.4)	0.35 (0.26;0.44)
16	cg15885148	CFAP61	9.4e-09	0.83 (0.73;0.92)	-0.05 (-0.12;0.02)	-0.13 (-0.22;-0.04)	-0.2 (-0.26;-0.14)
17	cg03254451	EN1	9.6e-09	0.04 (0;0.14)	0.02 (-0.05;0.09)	0.17 (0.08;0.27)	0.23 (0.16;0.29)
18	cg03653841	SFTA3	9.7e-09	0.03 (0;0.1)	0.01 (-0.05;0.07)	0.12 (0.04;0.19)	0.17 (0.12;0.22)
19	cg17857974	PCDHGA4;PCDHGA9;PCDHGA1;...	1.1e-08	0.14 (0.06;0.23)	0.05 (-0.02;0.11)	0.15 (0.06;0.23)	0.18 (0.13;0.24)
20	cg14457782	WNK4	1.1e-08	0.08 (0;0.17)	0 (-0.07;0.07)	0.05 (-0.04;0.14)	0.22 (0.16;0.28)
21	cg15582891	TAAR1	1.1e-08	0.87 (0.79;0.94)	-0.06 (-0.12;-0.01)	-0.06 (-0.13;0.01)	-0.15 (-0.2;-0.1)
22	cg20859731		1.2e-08	0.05 (0;0.16)	0.01 (-0.06;0.09)	0.14 (0.04;0.24)	0.26 (0.19;0.33)
23	cg12612118	IRF4	1.4e-08	0.08 (0;0.21)	0.02 (-0.08;0.12)	0.29 (0.16;0.42)	0.34 (0.25;0.43)
24	cg21183256		2.1e-08	0 (0;0.07)	0.04 (-0.05;0.13)	0.17 (0.06;0.29)	0.3 (0.22;0.38)

25	cg21277995	IRF4	2.3e-08	0.03 (0;0.16)	0.01 (-0.09;0.11)	0.16 (0.03;0.28)	0.28 (0.19;0.36)
26	cg11941811	TMEM108	2.4e-08	0.84 (0.74;0.94)	-0.05 (-0.12;0.02)	-0.07 (-0.17;0.02)	-0.23 (-0.29;-0.16)
27	cg20040743	NECAB1	2.7e-08	0.09 (0.02;0.15)	0 (-0.04;0.05)	0.08 (0.02;0.14)	0.14 (0.1;0.18)
28	cg01337836		2.9e-08	0.81 (0.74;0.89)	-0.03 (-0.09;0.02)	-0.06 (-0.13;0.01)	-0.17 (-0.21;-0.12)
29	cg03692651		3.00E-08	0 (0;0.15)	0.04 (-0.06;0.15)	0.26 (0.12;0.4)	0.4 (0.3;0.49)
30	cg11563680		3.6e-08	0.04 (0;0.14)	0.02 (-0.06;0.1)	0.17 (0.07;0.28)	0.31 (0.24;0.38)
31	cg13724788	NCAN	3.8e-08	0 (0;0.12)	0 (-0.09;0.09)	0.13 (0.02;0.25)	0.23 (0.15;0.31)
32	cg02623400	ELAVL4	3.9e-08	0 (0;0.05)	0.03 (-0.05;0.11)	0.24 (0.13;0.34)	0.28 (0.21;0.35)
33	cg24909548		3.9e-08	0.03 (0;0.18)	0 (-0.11;0.11)	0.27 (0.13;0.41)	0.37 (0.28;0.47)
34	cg19893751		4.6e-08	0.04 (0;0.16)	-0.01 (-0.09;0.08)	0.19 (0.08;0.3)	0.31 (0.24;0.38)
35	cg05380019		4.6e-08	0.08 (0;0.17)	0.02 (-0.05;0.09)	0.12 (0.03;0.21)	0.23 (0.17;0.3)
36	cg03181248	SP9	4.6e-08	0 (0;0.11)	0.04 (-0.04;0.12)	0.23 (0.13;0.34)	0.25 (0.17;0.32)
37	cg13677149	EVX1	4.6e-08	0 (0;0.13)	0.02 (-0.09;0.12)	0.19 (0.06;0.32)	0.37 (0.28;0.46)
38	cg22166999		4.8e-08	0.9 (0.83;0.98)	-0.02 (-0.08;0.03)	-0.1 (-0.18;-0.03)	-0.16 (-0.21;-0.11)
39	cg21433231		5.00E-08	0 (0;0.08)	-0.01 (-0.08;0.06)	0.11 (0.02;0.2)	0.22 (0.16;0.28)
40	cg05638493	SLC25A2	5.5e-08	0.29 (0.21;0.37)	0.03 (-0.03;0.08)	0.18 (0.1;0.25)	0.21 (0.16;0.26)
41	cg14559259	CCDC140	5.5e-08	0.09 (0;0.21)	0.02 (-0.07;0.11)	0.09 (-0.03;0.21)	0.3 (0.22;0.38)
42	cg16508480	ADAMTS16	6.00E-08	0 (0;0.1)	0 (-0.08;0.07)	0.2 (0.1;0.29)	0.26 (0.2;0.33)
43	cg18780257	FGF12	6.6e-08	0 (0;0.11)	0.01 (-0.08;0.09)	0.17 (0.06;0.28)	0.33 (0.26;0.41)
44	cg16073378		6.6e-08	0.01 (0;0.09)	0.01 (-0.05;0.07)	0.11 (0.02;0.19)	0.24 (0.18;0.29)
45	cg12788878	SLC12A8	7.00E-08	0.01 (0;0.12)	0.06 (-0.02;0.14)	0.24 (0.14;0.34)	0.27 (0.2;0.34)
46	cg12459904	PCDHGA4;PCDHGA6;PCDHGA1;...	7.1e-08	0.18 (0.09;0.28)	0.02 (-0.05;0.09)	0.19 (0.1;0.28)	0.25 (0.19;0.32)
47	cg11283429		7.1e-08	0.06 (0;0.17)	0.05 (-0.03;0.13)	0.18 (0.07;0.28)	0.27 (0.2;0.35)
48	cg07873041		7.1e-08	0.03 (0;0.16)	0 (-0.1;0.1)	0.24 (0.11;0.37)	0.4 (0.31;0.48)
49	cg03498096	INSM1	7.1e-08	0.08 (0;0.17)	0.02 (-0.05;0.09)	0.14 (0.04;0.23)	0.22 (0.16;0.29)
50	cg27252696	SIM1	7.5e-08	0 (0;0.08)	0.01 (-0.07;0.09)	0.11 (0;0.22)	0.27 (0.2;0.35)
51	cg26811372	PCDHGA4;PCDHGA6;PCDHGA1;...	7.7e-08	0.18 (0.08;0.28)	0.05 (-0.03;0.12)	0.26 (0.16;0.35)	0.26 (0.2;0.33)

52	cg15260349	MTNR1B	7.7e-08	0.15 (0.06;0.24)	0.05 (-0.01;0.12)	0.12 (0.03;0.2)	0.22 (0.16;0.28)
53	cg00824767		8.4e-08	0.06 (0;0.17)	0.02 (-0.06;0.1)	0.19 (0.08;0.29)	0.28 (0.2;0.35)
54	cg15672437	F7	8.5e-08	0 (0;0.09)	0 (-0.09;0.08)	0.14 (0.03;0.25)	0.29 (0.21;0.37)
55	cg11494930		8.6e-08	0.85 (0.79;0.91)	-0.03 (-0.07;0.01)	-0.07 (-0.13;-0.01)	-0.13 (-0.17;-0.09)
56	cg14189141		9.1e-08	0 (0;0.08)	0 (-0.08;0.08)	0.11 (0.01;0.21)	0.28 (0.21;0.35)
57	cg15138339	COASY	9.3e-08	1 (0.9;1)	-0.06 (-0.13;0.02)	-0.12 (-0.22;-0.02)	-0.24 (-0.31;-0.18)
58	cg05845376	SLC25A2	1.00E-07	0.17 (0.03;0.3)	0.03 (-0.07;0.14)	0.2 (0.07;0.33)	0.3 (0.21;0.4)
59	cg18490522	PRAC2;PRAC1	1.1e-07	0.1 (0;0.2)	0.02 (-0.05;0.1)	0.14 (0.04;0.23)	0.31 (0.24;0.38)
60	cg17759274		1.1e-07	0 (0;0.1)	0.12 (0.02;0.22)	0.26 (0.13;0.39)	0.34 (0.24;0.43)
61	cg18253016	NR2E1	1.1e-07	0.08 (0;0.17)	0 (-0.07;0.07)	0.17 (0.08;0.26)	0.24 (0.18;0.3)
62	cg16557178	HOXB13	1.1e-07	0.06 (0;0.16)	-0.01 (-0.09;0.07)	0.2 (0.1;0.3)	0.28 (0.21;0.35)
63	cg05785155		1.1e-07	0.04 (0;0.17)	0.03 (-0.06;0.13)	0.25 (0.13;0.38)	0.3 (0.21;0.39)
64	cg19509330	TFAP2D	1.1e-07	0.08 (0.01;0.16)	0.01 (-0.05;0.07)	0.12 (0.05;0.19)	0.18 (0.13;0.23)
65	cg13525197	ZSCAN23	1.1e-07	0.07 (0;0.15)	0.02 (-0.04;0.08)	0.13 (0.05;0.2)	0.2 (0.14;0.25)
66	cg23141355		1.1e-07	0.06 (0;0.2)	0.01 (-0.1;0.11)	0.15 (0.02;0.29)	0.28 (0.19;0.38)
67	cg26980244	NEFM	1.2e-07	0.05 (0;0.18)	0.03 (-0.06;0.13)	0.28 (0.16;0.4)	0.39 (0.3;0.47)
68	cg19671120	CNGA3	1.2e-07	0.13 (0.06;0.2)	0.02 (-0.03;0.07)	0.11 (0.05;0.18)	0.17 (0.13;0.22)
69	cg07920503	FAM123A	1.2e-07	0.07 (0;0.22)	0.04 (-0.07;0.15)	0.28 (0.14;0.42)	0.41 (0.31;0.51)
70	cg21684012	SIM1	1.2e-07	0 (0;0.07)	0.01 (-0.05;0.07)	0.13 (0.04;0.21)	0.25 (0.19;0.31)
71	cg00851770	CIDEA	1.2e-07	0.04 (0;0.16)	0.01 (-0.08;0.1)	0.18 (0.07;0.3)	0.29 (0.21;0.37)
72	cg21733531		1.3e-07	0.11 (0;0.23)	0.03 (-0.06;0.12)	0.26 (0.15;0.38)	0.29 (0.21;0.37)
73	cg04637478	PCDHGA4;PCDHGA1;PCDHGA6;...	1.3e-07	0.08 (0;0.18)	0.03 (-0.04;0.11)	0.18 (0.08;0.28)	0.25 (0.18;0.32)
74	cg14563954		1.3e-07	0.09 (0.01;0.17)	0 (-0.06;0.06)	0.07 (0;0.15)	0.2 (0.14;0.25)
75	cg02387803	ZIC4	1.3e-07	0.05 (0;0.18)	0.01 (-0.08;0.11)	0.11 (-0.02;0.23)	0.3 (0.21;0.39)
76	cg21790369	CACNA1E	1.3e-07	0.01 (0;0.14)	0.06 (-0.04;0.16)	0.19 (0.06;0.32)	0.23 (0.14;0.32)
77	cg00232292	UNC5D	1.3e-07	0.82 (0.74;0.89)	-0.01 (-0.06;0.05)	-0.1 (-0.17;-0.02)	-0.18 (-0.23;-0.13)
78	cg02328239	GDNF	1.3e-07	0.1 (0.02;0.17)	0.01 (-0.04;0.07)	0.16 (0.09;0.23)	0.18 (0.13;0.22)

79	cg25209842	FGF8	1.4e-07	0.01 (0;0.12)	0.03 (-0.05;0.12)	0.16 (0.04;0.27)	0.25 (0.18;0.33)
80	cg17018096	ADAMTS10	1.4e-07	0.1 (0.04;0.16)	0.01 (-0.04;0.05)	0.1 (0.04;0.16)	0.15 (0.11;0.19)
81	cg22601348		1.4e-07	0.04 (0;0.16)	0 (-0.08;0.09)	0.24 (0.13;0.35)	0.27 (0.2;0.35)
82	cg15347189	SST	1.4e-07	0.03 (0;0.13)	-0.01 (-0.09;0.07)	0.1 (0;0.2)	0.23 (0.16;0.3)
83	cg11885396	SLC6A17	1.4e-07	0 (0;0.07)	0.02 (-0.04;0.08)	0.15 (0.07;0.22)	0.2 (0.14;0.25)
84	cg12878812	SRRM4	1.5e-07	0.03 (0;0.12)	0.04 (-0.03;0.1)	0.17 (0.09;0.25)	0.26 (0.2;0.31)
85	cg18688293	NMBR	1.5e-07	0.08 (0;0.16)	0.01 (-0.05;0.07)	0.09 (0.01;0.17)	0.2 (0.15;0.25)
86	cg15191830	CCAT2;CASC8	1.5e-07	0.91 (0.8;1)	-0.04 (-0.12;0.04)	-0.12 (-0.23;-0.01)	-0.23 (-0.3;-0.16)
87	cg00495860		1.6e-07	0.04 (0;0.16)	0.01 (-0.08;0.09)	0.11 (-0.01;0.22)	0.28 (0.2;0.36)
88	cg18235734		1.6e-07	0.02 (0;0.13)	0 (-0.08;0.08)	0.22 (0.11;0.33)	0.36 (0.28;0.44)
89	cg21215550		1.6e-07	0.03 (0;0.18)	0.02 (-0.09;0.13)	0.08 (-0.07;0.22)	0.29 (0.19;0.39)
90	cg13160071		1.7e-07	0.9 (0.82;0.99)	-0.02 (-0.08;0.05)	-0.08 (-0.16;0)	-0.22 (-0.28;-0.16)
91	cg08942049	FGFR1	1.7e-07	0.85 (0.79;0.9)	-0.01 (-0.05;0.02)	-0.1 (-0.15;-0.05)	-0.13 (-0.16;-0.09)
92	cg01524853	HOXC4	1.8e-07	0.07 (0;0.17)	0.01 (-0.06;0.09)	0.17 (0.07;0.26)	0.23 (0.16;0.29)
93	cg10184983	SRCIN1	1.8e-07	0 (0;0.09)	0.03 (-0.06;0.12)	0.11 (-0.01;0.23)	0.26 (0.18;0.34)
94	cg07962143		1.8e-07	0.11 (0;0.24)	0.11 (0;0.21)	0.23 (0.1;0.36)	0.33 (0.24;0.42)
95	cg23421023	ZMAT4	1.9e-07	0.03 (0;0.15)	0.03 (-0.06;0.12)	0.16 (0.05;0.28)	0.23 (0.15;0.31)
96	cg13481132	KCNT1	1.9e-07	0.04 (0;0.13)	0.01 (-0.06;0.08)	0.03 (-0.06;0.12)	0.15 (0.09;0.21)
97	cg23612932		2,00E-07	0.41 (0.33;0.48)	0.07 (0.02;0.13)	0.13 (0.06;0.2)	0.17 (0.12;0.22)
98	cg24454829	SLC17A6	2,00E-07	0.09 (0.02;0.16)	0.05 (-0.01;0.1)	0.25 (0.18;0.32)	0.21 (0.16;0.26)
99	cg27331241	PRKAR1B	2,00E-07	0.02 (0;0.14)	0 (-0.08;0.09)	0.06 (-0.05;0.18)	0.23 (0.15;0.31)
100	cg27029821	PRDM14	2.1e-07	0.11 (0.01;0.2)	0.01 (-0.06;0.08)	0.16 (0.07;0.25)	0.25 (0.18;0.31)

Supplementary Table S4: Validation of methylation measurements in patient samples and the assessment of the effect of methylation on gene expression by 5-aza-dC treatment of the GBC cell lines G-415 and OZ.

Validation of differential methylation		Assessment of the effect of methylation on gene expression by treatment of GBC cell lines with 5-aza-dC or DMSO as a negative control											
Gene	CpG	EPIC Array		MassARRAY		GBC cell line G-415				GBC cell line OZ			
		β diff. GBC-GSD	p-value ¹	β diff. GBC-GSD	p-value ¹	β diff. Aza-DMSO	p-value ²	expr. fold change	p-value ²	β diff. Aza-DMSO	p-value ²	expr. fold change	p-value ²
<i>CDO1</i>	cg16707405	0.27	0.004	0.14	0.002	-0.17	0.04	32.3	4e-3	-0.20	0.04	29.5	0.002
<i>RUNX3</i>	cg26421310	0.11	0.40	0.07	0.20	-0.31	0.01	33.7	7e-7	-0.17	0.01	14.7	0.003
<i>TP73</i>	cg04493946	-0.08	0.02	-0.08	0.60	-0.10	0.30			-0.13	0.02		
<i>TP73</i>	cg07382920	0.37	4e-04	0.20	3e-04	-0.22	0.02			-0.08	0.48		
<i>TP73</i>	cg10038618	0.24	0.002	0.26	0.007	-0.22	0.01	4.6	3e-3	-0.10	0.19	1.0	0.78
<i>TP73</i>	cg24678611	0.22	0.003	0.14	0.04	-0.13	0.37			-0.23	0.11		
<i>TP73</i>	cg27340829	-0.08	0.20	-0.10	0.30	-0.07	0.04			-0.11	0.03		
<i>HMGA1</i>	cg08335767	-0.23	3e-04	-0.15	0.006	0.00	0.65	1.1	0.80	0.00	1.00	1.6	0.14
<i>HMGA1</i>	cg10610528	-0.09	0.07	-0.14	0.02	0.00	0.74			0.00	1.00		

β diff. GBC-GSD: Mean methylation difference between gallbladder cancer and gallstone disease samples; expr. fold change: fold change in expression

¹ Two-sample U-test p-value

² Two-sample t-test (single CpG) or ANOVA (multiple CpGs) p-value

Suppl. Table S5: Immunohistochemistry analysis of CD01 expression in GSD and GBC patients.

	Negative	Weak	Strong
GSD	0	1	4
GBC	4	2	0
Fisher test p=0.013			

Suppl. Table S6: Jonckheere-Terpstra test p-values of RNA-seq expression values across disease stages for genes detected as being significantly methylated along the progression GSD->LGD->HGD->GBC if sRNA-seq data for these genes passed quality control thresholds (see **Table 1**).

Gene	JT p-value
WWOX	2e-4
KCNMA1	3e-7
ZNF578	0.55
DPP6	0,067
ZNF177	0,46
EN1	0,007
PCDHGA4	4e-6
RPL22	0.7